


DIGITAL HOME CINEMA SYSTEM HT-DS460

Instruction Manual

















CLASS 1 LASER PRODUCT KLASSE 1 LASER PRODUKT LUOKAN 1 LASER LAITE KLASS 1 LASER APPARAT PRODUCTO LASER CLASE 1





CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE REAR COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL

DO NOT OPEN

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION-INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.



This symbol indicates that dangerous voltage which can cause electric shock is present inside this unit.



This symbol alerts you to important operating and maintenance instructions accompanying the unit.

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

Wiring the Main Power Supply Plug(UK Only)

IMPORTANT NOTICE

The main lead on this equipment is supplied with a moulded plug incorporating a fuse. The value of the fuse is indicated on the pin face of the plug and if it requires replacing, a fuse approved to BS1362 of the same rating must be used.

Never use the plug with the fuse cover removed. If the cover is detachable and a replacement is required, it must be of the same colour as the fuse fitted in the plug. Replacement covers are available from your dealer.

If the fitted plug is not suitable for the power points in your house or the cable is not long enough to reach a power point, you should obtain a suitable safety approved extension lead or consult your dealer for assistance.

However, if there is no alternative to cutting off the plug, remove the fuse and then safely dispose of the plug. Do not connect the plug to a main socket as there is a risk of shock hazard from the bared flexible cord.

Never attempt to insert bare wires directly into a main socket. A plug and fuse must be used at all times.

IMPORTANT

The wires in the main lead are coloured in accordance with the following code:-


BLUE = NEUTRAL BROWN = LIVE


As these colours may not correspond to the coloured markings identifying the terminals in your plug, proceed as follows:-

The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLUE or BLACK. The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured BROWN or RED.


WARNING: DO NOT CONNECT EITHER WIRE TO THE EARTH TERMINAL WHICH IS MARKED WITH THE LETTER E OR BY THE EARTH SYMBOL $\stackrel{}{=}$, OR COLOURED GREEN OR GREEN AND YELLOW.








Ensure that the AC power supply in your house complies with the identification sticker located on the back of your player. Install your player horizontally, on a suitable base (furniture), with enough space around it for ventilation (3-4inches). Make sure the ventilation slots are not covered. Do not stack anything on top of the player. Do not place the player on amplifiers or other equipment which may become hot. Before moving the player, ensure the disc tray is empty. This player is designed for continuous use. Switching off the DVD player to the stand-by mode does not disconnect the electrical supply. In order to disconnect the player completely from the power supply, remove the main plug from the wall outlet, especially when left unused for a long period of time.




During thunderstorms, disconnect AC main plug from the wall outlet.

Voltage peaks due to lightning could damage the unit.



Do not expose the unit to direct sunlight or other heat sources

This could lead to overheating and malfunction of the unit.




Protect the player from moisture(i.e. vases), and excess heat(e.g.fire-place) or equipment creating strong magnetic or electric fields (i.e.speakers...). Disconnect the power cable from the AC supply if the player malfunctions. Your player is not intended for industrial use.

Use of this product is for personal use only.

Condensation may occur if your player or disc have been stored in cold temperatures.

If transporting the player during the winter, wait approximately 2 hours until the unit has reached room temperature before using.



The battery used with this product contain chemicals that are harmful to the environment.

Do not dispose of batteries in the general household trash.



Multi-Disc Playback & AM/FM Tuner

The HT-DS460 combines the convenience of multi-disc playback capability, including DVD-AUDIO, DVD-VIDEO, VCD, CD, MP3-CD, DivX, CD-R/RW, and DVD-R/RW, with a sophisticated AM/FM tuner, all in a single player.

DVD-Audio compatible

Experience the super high-quality audio performance of DVD-Audio. The on-board 24-bit/192kHz DAC enables this player to deliver exceptional sound quality in terms of dynamic range, low-level resolution and high-frequency detail.

OSuper Digital Sound Master

Equipped with new digital audio technology (RRSS, Live Surround Mode, Virtual headphone) developed in cooperation with DiMagic Co., Ltd., for full, spacious sound and easy control.



ORRSS (Rear Reflecting Surround System)

The sound from the rear speaker is reflected against the side and rear walls before reaching the listener to produce realistic sound as if you have installed an actual 5.1-channel speaker system.

P.SCAN (progressive Scan) Function

Unlike regular interlace Scan ,in which two fields of picture information alternate to create the entire picture (odd scan lines, then even scan lines), Progressive Scan uses one field of information (all lines displayed in one pass) to create a clear and detailed picture without visible scan lines.

TV Screen Saver Function

The HT-DS460 automatically brightens and darkens the brightness of the TV screen after 3 minutes in the stop mode.

The HT-DS460 automatically switches itself into the power saving mode after 20 minutes in the screen saver mode.

Power Saving Function

The HT-DS460 automatically shuts itself off after 20 minutes in the stop mode.

Customized TV Screen Display

The HT-DS460 allows you to select your favorite image during JPEG, DVD, or VCD playback and set it as your background wallpaper.



	PREPARATION	
	Safety Warnings Precautions	1
	Features	
	Notes on Discs	
	Description	7
0	CONNECTIONS	
-	Connecting the Speakers	11
	Connecting the Video Out to TV	
	P.SCAN(Progressive Scan) Function	
	Connecting the FM and AM Antennas	
	Before Using Your DVD Player	19
0	OPERATION	
	Disc Playback	2
	Checking the Remaining Time	22
	MP3-CD Playback	
	DivX Playback	2
	Displaying Disc Information	2
	Fast/Slow Playback	
	Skipping Scenes/Songs	
	A-B Repeat Playback	3
	Angle Function	32
	Zoom Function	
	Selecting Audio/Subtitle Language	
	Moving Directly to a Scene/Song	30
	Using Disc Menu	3
0	Using the Title Menu	30
\bigcirc	SETUP	
	Setting the Language	39
	Setting TV Screen type	4
	Setting the Password	4
	Setting the Wallpaper	
	DVD Playback Mode	
	Setting the Speaker Mode	
	Setting the Test Tone	52
	Setting the Delay Time	
	Setting the Audio Quality	
	Dolby Pro Logic II Mode	59
	Dolby Pro Logic II Effect	
	Setting the RRSS(Rear Reflecting Surround System)	
	Live Surround Mode	
	SURROUND PLUS / Virtual Headphone	6
	SUPER 5.1	60
	RADIO OPERATION	
_	Listening to Radio	
	Presetting Stations	
		0
	MISCELLANEOUS	-
	Convenient Functions	
	Before Calling for Service	7; 7;
	Cautions on Handling and Storing Discs	7
	Specifications	
	Memo	





DVD (Digital Versatile Disc) offers fantastic audio and video, thanks to Dolby Digital surround sound and MPEG-2 video compression technology. Now you can enjoy these realistic effects in the home, as if you were in a movie theater or concert hall.





DVD players and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.

The Region Number for this player is given on the rear panel of the player. (Your DVD player will only play DVDs that are labeled with identical region codes.)

Playable Discs

Disc Type	Mark (Logo)	Recorded Signals	Disc Size	Max. Playing Time	
	AUDIO/VIDEO	Audio + Video	12cm	Approx. 240 min. (single-sided)	
DVD-AUDIO			12011	Approx. 480 min. (double-sided)	
DVD-VIDEO			8cm	Approx. 80 min. (single-sided)	
				Approx. 160 min. (double-sided)	
VIDEO-CD	DIGITAL VIDEO	Audio + Video	12cm	74 min.	
VIDEO-CD			8cm	20 min.	
ALIDIO OD	DIGITAL AUDIO	Audio	12cm	74 min.	
AUDIO-CD			8cm	20 min.	

(Z)

Do not use the following types of disc!

- LD, CD-G, CD-I, CD-ROM and DVD-ROM cannot be played on this player.

 If such discs are played, a "WRONG DISC FORMAT" message appears on the TV screen.
- DVD discs purchased abroad may not play on this player.

 If such discs are played, a "WRONG REGION CODE" message appears on the TV screen.

Copy Protection

- Many DVD discs are encoded with copy protection. Because of this, you should only connect
 your DVD player directly to your TV, not to a VCR. Connecting to a VCR results in a distorted picture from copy-protected DVD discs.
- This product incorporates copyright protection technology that is protected by methods claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Disc Recording Format

CD-R Discs

- Depending on the disc recording device (CD-Recorder or PC) and the condition of the disc, some CD-R discs may not be playable.
- Use a 650MB/74 minute CD-R. Avoid CD-R media, as they may not be playable.
- If possible, do not use CD-RW (Rewritable) media, as they may not be playable.
- Only the CD-Rs that are properly "closed" can be fully played. If the session is closed but the disc is left open, you may not be able to fully play the disc.

CD-R MP3 Discs


- Only CD-R discs with MP3 files in ISO 9660 or Joliet format can be played.
- MP3 file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- Use discs recorded with a compression/decompression data rate greater than 128Kbps.
- Only files with the ".mp3" and ".MP3" extensions can be played.
- Only a consecutively written Multisession disc can be played. If there is a blank segment in the Multisession disc, the disc can be played only up to the blank segment.
- If the disc is not closed, it will take longer to begin playback and not all of the recorded files may be played.
- For files encoded in Variable Bit Rate (VBR) format, i.e. files encoded in both low bit rate and high bit rate (e.g., 32Kbps ~ 320Kbps), the sound may skip during playback.
- If more than 500 tracks are recorded on a single CD, a maximum of 500 tracks can be played.
- If more than 300 folders are recorded on a single CD, a maximum of 300 folders can be played.


CD-R JPEG Discs

- Only files with the ".jpeg" and ".JPEG" extensions can be played.
- If the disc is not closed, it will take longer to start playing and not all of the recorded files may be played.
- Only CD-R discs with JPEG files in ISO 9660 or Joliet format can be played.
- JPEG file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- Only a consecutively written multisession disc can be played. If there is a blank segment in the multisession disc, the disc can be played only up to the blank segment.
- A maximum of 9,999 images can be stored on a single CD.
- When playing a Kodak/Fuji Picture CD, only the JPEG files in the picture folder can be played.
- Picture discs other than Kodak/Fuji Picture CDs may take longer to start playing or may not play at all.


Description

—Front Panel—






7




Accessories

Connect the TV's video input jacks (VIDEO IN) to the VIDEO OUT connector.





—Remote Control—




Insert Remote Batteries


1 Remove the battery cover on the back of the remote by pressing down and sliding the cover in the direction of the arrow.



2 Insert two 1.5V AAA batteries, paying attention to the correct polarities (+ and –).



Replace the battery cover.




Caution

Follow these precautions to avoid leaking or cracking cells:

- Place batteries in the remote control so they match the polarity:(+) to (+)and (-)to (-).
- Use the correct type of batteries. Batteries that look similar may differ in voltage.
- Always replace both batteries at the same time.
- Do not expose batteries to heat or flame.

Range of Operation of the Remote Control

The remote control can be used up to approximately 23 feet/7 meters in a straight line. It can also be operated at a horizontal angle of up to 30° from the remote control sensor.




To open the remote control cover, push the top of the cover, then slide downward.





Connecting the Speakers

Before moving or installing the product, be sure to turn off the power and disconnect the power cord.



Position of the DVD Player

• Place it on a stand or cabinet shelf, or under the TV stand.

Front Speakers **DR** / **BR**

- Place these speakers in front of your listening position, facing inwards (about 45°) toward you.
- Place the speakers so that their tweeters will be at the same height as your ear.
- · Align the front face of the front speakers with the front face of the center speaker or place them slightly in front of the center speakers.

Center Speaker C



- It is best to install it at the same height as the front
- You can also install it directly over or under the TV.


Selecting the Listening Position

The listening position should be located about 2.5 to 3 times the distance of the TV's screen size away from the TV. Example: For 32" TVs 2~2.4m (6~8feet) For 55" TVs 3.5~4m (11~13feet)

Subwoofer W

- The position of the subwoofer is not so critical. Place it anywhere you like.
- Usually, it is placed by a corner near the front speakers.

•Connect the front/rear, center, and subwoofer speakers to the speaker terminals on the back of the main unit.




Back of the Speakers

1 Press down the terminal tab on the back of the speaker.



- 2 Insert the wire into the terminal and release the terminal tab.
 - Insert the black wire into the black

 (-) terminal and the gray wire into the gray (+) terminal.
 - Make sure the polarities (+ and -) are correct.




Caution

- Do not let children play with the speakers. They could get hurt if a speaker falls.
- When connecting the speaker wires to the speakers, make sure that the polarity (+/-) is correct.
- Never touch the speaker terminal while the power is on.
 Doing so may result in a risk of electric shock.

Back of the Main Unit

- 3 Connect the connecting jacks to the back of the DVD player.
 - Make sure the colors of the speaker terminals match the colors of the connecting jacks.




Note

 If you place a speaker near your TV set, screen color may be distorted because of the magnetic field generated by the speaker. In this case, place the speaker away from your TV set.



Connecting the Video Out to TV

Make sure that turn off and disconnect the plug from outlet before moving or installing the product. In connecting to video, select one of following three methods that suits for TV and connect it.



METHOD 1 Composite Video Good Quality

Connect the supplied video cable from the VIDEO OUT jack on the back panel of the system to the VIDEO IN jack on your television.

METHOD 2 Scart Better Quality

If you television is equipped with an SCART input, connect an Scart Jack (not supplied) from the AV OUT jack on the back panel of the system to the SCART IN jack on your television.

For using the SCART cable

- If Scart is equipped for your TV, set RGB-COMPOSITE selector of the center unit to RGB. You can get a better picture quality by using Scart setting.
- If Scart (RGB Input) is not equipped for your TV, set RGB-COMPOSITE selector to COMPOSITE.





METHOD 3 Component (Progressive Scan) Video Best Quality

If your television is equipped with Component Video inputs, connect a component video cable (not supplied) from the Pr, Pb and Y jacks on the back panel of the system to the corresponding jacks on your television.

Note

 When the Progressive scan mode is selected, the VIDEO and SCART outputs do not feed any signal. See page 14 to select Progressive Scan.



P.SCAN(Progressive Scan) Function

Unlike regular Interlace Scan, in which two fields of picture information alternate to create the entire picture (odd scan lines, then even scan lines), Progressive Scan uses one field of information (all lines displayed in one pass) to create a clear and detailed picture without visible scan lines.

Press and hold P.SCAN button on the remote controller for over 5 seconds in stop mode.

"P.SCAN" or "I.SCAN" will appear in the display.
 At this time, press the P.SCAN button shortly to select between "P.SCAN" and "I.SCAN".

What is Progressive (or Non-Interlaced) Scanning?

Interlaced Scan (1 FRAME = 2 FIELDS)

even add ----


In interlaced-scan video, a frame consists of two interlaced fields (odd and even), where each field contains every other horizontal line in the frame.

The odd field of alternating lines is displayed first, and then the even field is displayed to fill in the alternating gaps left by the odd field to form a single frame.

One frame, displayed every 1/30th of a second, contains two interfaced fields, thus a total of 60 fields are dis-

played every 1/60th of a second. The interlaced scanning method is intended for capturing a still object.

Progressive Scan (FULL FRAME)



The progressive scanning method scans one full frame of video consecutively down the screen, line by line. An entire image is drawn at one time, as opposed to the interlaced scanning process by which a video image is drawn in a series of passes.

The progressive scanning method is desirable for dealing with moving objects.



- This function works only on TVs equipped with component video inputs (Y, Pr, Pb) that support Progressive Video. (It does not work on TVs with conventional component inputs, i.e., non-progressive scan TVs.)
- Depending on the brand and model of your TV, this function may not work.

Selecting the Video Format

Press and hold NTSC/PAL button on the remote controller for over 5 seconds while the power is turned off.


- "NTSC" or "PAL" will appear in the display.
 At this time, press the NTSC/PAL button shortly to select between "NTSC" and "PAL".
- Each country has a different video format standard.
- For normal playback, the video format of the disc must be the same as the video format of your TV.



Connecting External Components

Connecting an External Digital Component


Example: Digital signal components such as a Set-Top Box or CD Recorder.



- 1 Connect the Digital Input (OPTICAL) to the Digital Output on the external digital component.
- 2 Press AUX on the remote control to select 'DIGITAL IN'.
 - Each time the button is pressed, the selection changes as follows: DIGITAL IN → AUX 1 → AUX 2.
 - You can also use the FUNCTION button on the main unit.
 The mode switches as follows: DVD/CD → DIGITAL IN → AUX1 → AUX2 → FM → AM.

Connecting an External Analog Component


Example: Analog signal components such as a VCR or TV.



- 1 Connect Audio In on the DVD player to Audio Out on the external analog component.
 - Be sure to match connector colors.
- **2** Press **AUX** on the remote control to select AUX 1 or AUX 2.
 - Each time the button is pressed, the selection changes as follows: DIGITAL IN → AUX 1 → AUX 2.
 - You can also use the FUNCTION button on the main unit.
 The mode switches as follows: DVD/CD → DIGITAL IN → AUX1 → AUX2 → FM → AM.



Connecting the FM and AM Antennas



FM antenna connection


- 1. Connect the FM antenna supplied to the FM 75 Ω COAXIAL terminal as a temporary measure.
- 2. Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.

AM antenna connection

- 1. Connect the AM loop antenna supplied to the AM and # terminals.
- 2. If reception is poor, connect an outdoor single vinyl-covered wire to the AM terminal. (Keep the AM loop antenna connected).
 - If reception is poor, connect an outdoor antenna.
 Before attaching a 75Ω coaxial cable (with a standard type connector), disconnect the supplied FM antenna.

Cooling Fan

The cooling fan dissipates the heat generated inside the unit so that the unit can be operated normally. The cooling fan is activated automatically to supply cool air to the unit.



Please observe the following cautions for your safety.

- Make sure the unit is well-ventilated. If the unit has poor ventilation, the temperature inside the unit could rise and may damage it.
- Do not obstruct the cooling fan or ventilation holes. (If the cooling fan or ventilation holes are covered with a newspaper or cloth, heat may build up inside the unit and fire may result.)



Before Using Your DVD Player

Your DVD player is capable of playing DVD, VCD, CD, MP3 and JPEG discs. Depending on the disc you are using, these instructions may vary slightly. Read the instructions carefully before using.

Plug the power cord into the AC power supply.

Press the MODE button so that the TV indicator on the remote control flashes.



Press the POWER button to turn on the TV.



Press TV/VIDEO button to select VIDEO mode.



Press the MODE button so that the DVD RECEIVER indicator on the remote control flashes.



6 Press DVD button to select DVD/CD mode.

Selecting the Video Format


Turn off the main unit and then press NTSC/PAL.

- By default, the video format is set to "PAL".
- Each time the button is pressed, the video format switches between "NTSC" and "PAL".
- Each country has a different video format standard.
- For normal playback, the video format of the disc must be the same as the video format of your TV.

To Operate the TV and DVD Player with a Single Remote Control

Press MODE button.


- Each time the button is pressed, the TV indicator (red) and the DVD Receiver indicator (green) will flash alternately.
- You can operate the TV while the TV indicator is flashing and the DVD player while the DVD indicator is flashing.
- Buttons Enabled for TV Operation: POWER, CHANNEL, VOLUME, TV/VIDEO, and Numeric (0-9) buttons.
- By default, the remote control is set to work with Samsung TVs. See page 65 for more information on the operation of the remote control.



Disc terminology


Groups and tracks (DVD-AUDIO)

 DVD-audios are divided into several large sections called "groups" and smaller sections called "tracks". Numbers are allotted to these sections. These numbers are called "group numbers" and "track numbers".




Titles and chapters (DVD-VIDEO)

 DVD-videos are divided into several large sections called "titles" and smaller sections called "chapters". Numbers are allotted to these sections.
 These numbers are called "title numbers" and "chapter numbers".



Tracks (Video and music CDs)

Video and music CDs are divided into sections called "tracks".
 Numbers are allotted to these sections. These numbers are called "track numbers".



- Note
- In this manual, the instructions marked with "DVD (DVD)" are applicable to DVD-VIDEO, DVD-AUDIO, and DVD-R/RW discs.
 Where a particular DVD type is mentioned, it is indicated separately.
- Depending on the content of the disc, the initial screen may appear different.



Press **OPEN/CLOSE** button to open the disc trav.

- Load a discs.
- Place a disc gently into the tray with the disc's label facing up.
- Press OPEN/CLOSE button to close the disc trav.








• Playback starts automatically.

Note

- Depending on the content of the disc, the initial screen may appear different.
- Depending on the recording mode, some MP3-CDs cannot be played.
- Table of contents of a MP3-CD varies depending on the MP3 track format recorded on the disc.

To stop playback, press STOP during playback.

- If pressed once, "PRESS PLAY" is displayed and the stop position will be stored in memory. If PLAY/PAUSE (►/II) button or ENTER button is pressed, playback resumes from the stop position. (This function works only with DVDs.)
- If pressed twice, "STOP" is displayed, and if PLAY/PAUSE (►/II) button is pressed, playback starts from the beginning.



To temporarily pause playback, press PLAY/PAUSE during playback.

• To resume playback, press PLAY/PAUSE (►/II) button again.





Checking the Remaining Time


Press the REMAIN button.


• For checking the total and remaining time of a title or chapter being played.

Each time the REMAIN button is pressed












MP3-CD Playback

Data CDs (CD-ROM, CD-R, CD-RW) encoded in MP3 format can be played.


- Press the
 OPEN/CLOSE button
 to open the disc tray,
 and then load the
 MP3 disc.
- The MP3 menu screen will appear and playback will start.
- Depending on the MP3 disc, the appearance of the menu may be different.





- To change the album, use ◀ ▶ ▲ ▼ to select another album in Stop mode, and then press the ENTER button.
- To select another album and track, repeat Steps 2 and 3 above.

Press the STOP button to stop playback.



Note

- Depending on the recording mode, some MP3-CDs may not play.
- Table of contents of a MP3-CD varies depending on the MP3 track format recorded on the disc.




JPEG Disc Playback

Images captured with a digital camera or camcorder, or JPG files on a PC can be stored on a CD and then played back with this unit.

Press the **OPEN/CLOSE** button to open the disc tray, and then load the JPEG disc.

• Playback will start automatically and each image will show for 5 seconds before moving to the next image.





Skip Forward/Back


During playback, press the I◄◄ ▶► button.

- Go to the next file whenever you press ►►I button, if there are over 2 files in the disk.

Fast playback

Press and hold I◀◀ ▶►I button.

• Each time the button is held down during playback, the playback speed changes as follows:




Zoom Function

Press **ZOOM** button.

 Each time you press the button, your selection will toggle between "ZOOM X2" and "ZOOM OFF". Press Cursor ▲ ,▼ ,

◀ ,▶ buttons to
move to the area
you want to enlarge.



Note

 DIVX file can be zoomed only in ZOOM X2 mode.

5 Minute Skip function

During playback, press the ◀ ,▶ button.

- Go to the screen about 5 minutes after whenever you press ▶ button.
- Go to the screen about 5 minutes earlier whenever you press ■ button.

Subtitle Display

If the disc has more than one subtitle file

If the disc has more than one subtitle file, the default subtitle may not match the movie and you will have select your subtitle language as follows:

- In Stop mode, press the **ENTER** button, select the desired subtitle (🖃) from the TV screen, and then press the **ENTER** button.
- 2 When you select the desired DivX file from the TV screen, the movie will be played normally.

DivX Feature Table

DivX Supported

Avi files are used to contain the audio and video data; these must be stored on CD in the ISO 9660 format.

		SPEC
VIDEO Compatibility	DivX3.11	Up to the latest VERSION
	WMV	WMV V1/V2/V3/V7
AUDIO Compatibility	MP3	CBR: 80kbps~320kbps
	AC3	CBR: 128kbps~448kbps
	WMA	CBR: 56kbps~160kbps

MPEGs containing DivX can be divided into Video and Audio.

- Video compatibility: All versions of DivX later than 3.11 (including the latest 5.1) are supported. In addition, XviD is supported.
 For WMV, V1, V2, V3, and V7 formats are possible.
- Audio compatibility: MP3s encoded at bitrates from 80kbps to 320kbps, AC3s from 128kbps to 448kbps, and WMAs from 56kbps to 160kbps are supported.
- In addition, for subtitles, this unit will support Text format (SMI).

Note

- When playing the DivX disk, you can play the file with extension of AVI only.
- Among the available DivX audio formats, DTS Audio is not supported.
- WMV V8 is not supported for WMV files.
- When burning a subtitle file to a CD-ROM with your PC, be sure to burn it as an SMI file.
- DivX Disc does not playing when its sampling frequency is lower than 32kHz.



Displaying Disc Information

You can view disc playback information on the TV screen.

Press **INFO** button

• Each time the button is pressed, the display changes as follows:












Display disappears

Note

- · Depending on the disc, the disc information display may appear different.
- Depending on the disc, you can also select DTS. DOLBY DIGITAL, or PRO LOGIC



appears on the TV screen!

If this symbol appears on the TV screen while buttons are being operated, that operation is not possible with the disc currently being played.

CO OFF

e SMART NAV

• What is a Group?

A movie contained in a DVD-AUDIO disc.

What is a Title?


A movie contained in a DVD-VIDEO disc.

What is a Chapter?

Each title on a DVD disc is divided into several smaller sections called "chapters".


What is a Track (File)?

A section of video or a music file recorded on a DVD-AUDIO, CD, or MP3-CD.






Fast/Slow Playback







Slow Playback


Press **SLOW** button.

4I 1/4

4I 1/8

► PLAY

• Each time the button is pressed during playback,



Note

 Reverse slow playback does not work with VCD and DivX.



Skipping Scenes/Songs







Briefly press ► .

• Each time the button is pressed briefly during playback, the previous or next chapter. track, or directory (file) will be played.

















• When watching a VCD with a track longer than 15 minutes, each time is pressed, playback will skip back or forward 5 minutes.














Note

- During fast playback of a CD or MP3-CD, sound is heard only at 2x speed, and not at 4x, 8x, and 32x speeds.
- No sound is heard during slow playback and step motion playback.



Repeat Playback

Repeat playback allows you to repeatedly play a chapter, title, track (song), or directory (MP3 file).













Press **RFPFAT** button

• Each time the button is pressed during playback, the repeat playback mode changes as follows:





Repeat Playback Options

CHAPTER

Repeatedly plays the selected chapter.

TITI F

Repeatedly plays the selected title.

RANDOM

Plays tracks in random order. (A track that has already been played may be played again.)

TRACK

Repeatedly plays the selected track.

סוח

Repeatedly plays all tracks in the selected folder.

DISC


Repeatedly plays the entire disc.

OFF

Cancels Repeat Playback.

To Select a Repeat Playback Mode in the Disc Information Screen

- 1 Press **INFO** button twice.
- 2 Press Cursor ▶ button to move to REPEAT PLAY-BACK (♣) display.
- 3 Press Cursor ▼ button to select the desired Repeat Playback mode.
- 4 Press ENTER button.
- * For MP3 and JPEG discs, you cannot select Repeat Play from the information display screen.



C) TRACK

CDISC

Note

 Repeat playback operation is not possible with version 2.0 VCD discs if PBC is turned on. To use Repeat Playback on a VCD with PBC, you should set the PBC to OFF in the disc menu. (See page 39.)



A-B Repeat Playback



- Press **INFO** button twice.
- For a VCD or CD, press INFO button once.



Press Cursor ► button to move to REPEAT PLAYBACK (₾⊋) display.



- Press Cursor ▲, ▼ buttons to select 'A-' and then press ENTER button at the beginning of the desired segment.
- When ENTER button is pressed, the selected position will be stored in memory.




- Press ENTER button at the end of the desired segment.
- The specified segment will be played repeatedly.

DVD		EN		D I G I T A L				₫⊋ A - B
REPEAT : A—B								

To return to normal playback, press Cursor ▲, ▼ buttons to select Ĉ⊋ OFF.



• The A-B Repeat function will not work on an MP3 or JPEG disc.





Angle Function

This function allows you to view the same scene in different angles.







- Press Cursor ▲, ▼ or numeric buttons to select the desired angle.
- Each time the button is pressed, the angle changes as follows:











 The Angle function works only with discs on which multiple angles have been recorded.



Zoom Function

This function allows you to enlarge a particular area of the displayed image.



Zoom (Screen Enlarge) Function



Press **ZOOM** but-


Press Cursor ▲, ▼,
◀, ▶ buttons to
move to the area you want to enlarge.







• Each time the button is pressed, the zoom level changes as follows:



- Aspect Ratio



Press **EZ VIEW** button.

- Each time the button is pressed, the zoom function will switch between On
- When a movie is played in Widescreen format, black bars at the top and bottom of the TV screen can be removed by pressing the **EZ VIEW** button.




Note

- This function will not work if the DVD is recorded with multi-camera angle format.
- Black bars may not disappear because some DVD discs have a built-in horizontal to vertical ratio.



Bonus Group / Navigating Pages





Some DVD-Audio discs have an extra 'bonus' group that requires a 4-digit key number to access. See the disc packaging for details and the-key number.

When you play a DVD-Audio disc that has a bonus group, the key number input screen appears automatically.



Note

• If you eject the disc, switch the power off, or unplug the player, you will need to re-enter the key number.





During playback, press the 🛇 button on the remote control.

- You can select the desired image from a DVD-Audio disc containing still images.
- With some discs, you may not be able to select images depending on how the disc was manufactured.



Selecting Audio/Subtitle Language

- Audio Language Selection Function







- Press Cursor ▲ ,▼ buttons or numeric buttons to select the desired audio language.
- Depending on the number of languages on a DVD disc, a different audio language (ENG-LISH, SPANISH, FRENCH, etc.) is selected each time the button is pressed.




Subtitle Language Selection Function



Press Cursor ▶ button to move to SUBTITLE (🔙) display.

Press Cursor ▼ button or numeric buttons to select the desired subtitle.





- You can use the SUBTITLE button on the remote control to select a subtitle language.
- Depending on the disc, the Subtitle and Audio Language functions may not work.



Moving Directly to a Scene/Song





Moving to a Title/Track

Press Cursor A, buttons or numeric buttons to select the desired title/track and then press ENTER button.



Moving to a Chapter

Press Cursor ◀,► buttons to move to Chapter (♣) display.



Moving to a Chapter

Press Cursor ▲, ▼ buttons or numeric buttons to select the desired chapter and then press ENTER button.



Moving to a Specific Time

Press Cursor ◀, ► buttons to move to time display.



Moving to a Specific Time

Press the numeric buttons to select the desired time and then press **ENTER** button.





Press the **numeric** buttons.

- The selected file will be played.
- An MP3 or JPEG disc cannot be moved from the disc information screen.
- When playing an MP3 or JPEG disc, you cannot use ▲ ,▼ to move a folder.
 To move a folder, press (Stop) and then press ▲ ,▼ .



Note

- You can press I◄◀►►I on the remote control to move directly to the desired title, chapter, or track.
- Depending on the disc, you may not be able to move to the selected title or time.



Using Disc Menu

You can use the menus for the audio language, subtitle language, profile, etc. DVD menu contents differ from disc to disc.



- In Stop mode, press **MENU** button.
- When playing a VCD (version 2.), this toggles between PBC ON and OFF.



Press Cursor ▲,▼

◀, ▶ buttons to select the desired item.




Press Cursor ▲ ,▼ buttons to move to 'DISC MENU' and then press ENTER button.

When you select the disc menu that is not supported by the disc, the "This menu is not supported" message appears on the screen.



Press ENTER button.





Note

PBC (Playback Control) Function

Press the MENU button while VCD 2.0 version disk is played.

Each time you press the button, "PBC ON" and "PBC OFF" will be repetitively selected in the display.

- PBC ON: This VCD disc is version 2.0. The disc is played back according to the menu screen.

 Some functions may be disabled. When some functions are disabled, select "PBC OFF" to enable them.
- PBC OFF: This VCD disc is version 1.1. The disc is played back in the same way as with a music CD.



Using the Title Menu

For DVDs containing multiple titles, you can view the title of each movie. Depending on the disc, this function may either not work at all or may work differently.



- In Stop mode, press **MENU** button.
 - DISC MENU

 DISC MENU

 Press Enter key
 for Disc Menu

 Audio

 Setup

 MOVE SELECT

 DISC MENU

 Press Enter key
 for Disc Menu

 For Disc Menu

 DISC MENU

 Press Enter key
 for Disc Menu

 For Disc Menu

 DISC MENU

 Press Enter key
 for Disc Menu

 For Disc Menu

 DISC MENU

 Press Enter key
 for Disc Menu

 For Disc Menu

 DISC MENU

 Press Enter key
 for Disc Menu

 DISC MENU

 DISC MENU

 Press Enter key
 for Disc Menu

 DISC MENU

 DISC MENU

 Press Enter key
 for Disc Menu

 DISC ME
- Press Cursor ▲ ,▼ button to move to 'Title Menu'.



- Press ENTER button.
 - The title menu appears.




Press MENU button to exit the setup screen.



Setting the Language

OSD language is set to English by default.



In Stop mode, press **MENU** button.



Press Cursor ▼
button to move to
'Setup' and then
press ENTER button.



Press **RETURN** button to return to the previous level.

Press **MENU** button to exit the setup screen.

- Press ENTER button.
- Press Cursor ▲,▼
 button to select the
 desired item and then
 press ENTER button.
 - DISC MENU : KOREAN AUDIO : ROGEN

 * AUDIO : RNGLISH AUDIO : RNGRAN AUDIO :
- Press Cursor ▲ ,▼
 button to select the
 desired language and then
 press ENTER button.
- Once the setup is complete, if the language was set to English, OSD will be displayed in English.





Selecting the OSD Language



Selecting the Audio Language (recorded on the disc)



Selecting the Subtitle Language (recorded on the disc)




Selecting the Menu Language (recorded on the disc)

* If the language you selected is not recorded on the disc, menu language will not change even if you set it to your desired language.



Setting TV Screen type

Depending on your TV type (Wide Screen TV or conventional 4:3 TV), you can select the TV's aspect ratio.



In Stop mode, press **MENU** button.



Press Cursor ▼
button to move to
'Setup' and then
press ENTER button.



Press Cursor ▼
button to move to 'TV
DISPLAY' and then
press ENTER button.



- Press Cursor ▲,▼
 button to select the
 desired item and then
 press ENTER button.
- Once the setup is complete, you will be taken to the previous screen.



Press **RETURN** button to return to the previous level.

Press MENU button to exit the setup screen.

Adjusting the TV Aspect Ratio (Screen Size)

The horizontal to vertical screen size ratio of conventional TVs is 4:3, while that of wide screen and high definition TVs is 16:9. This ratio is called the aspect ratio. When playing DVDs recorded in different screen size, you should adjust the aspect ratio to fit your TV or monitor.

★ For a standard TV, select either "4:3LB" or "4:3PS" option according to personal preference. Select "16:9" if you have a wide screen TV.

WIDE

- : Select this to view a 16:9 picture in the full-screen mode on your wide screen TV.
- You can enjoy the wide screen aspect.



4:3LB (4:3 Letterbox)

- : Select this to play a 16:9 picture in the letter box mode on a conventional TV.
- Black bars will appear at the top and bottom of the screen.



4:3PS (4:3 Pan&Scan)

- : Select this to play a 16:9 picture in the pan & scan mode on a conventional TV.
- You can see the central portion of the screen only (with the sides of the 16:9 picture cut off).




Note

- If a DVD is in the 4:3 ratio, you cannot view it in wide screen.
- Since DVD discs are recorded in various image formats, they will look different depending on the software, the type of TV, and the TV aspect ratio setting.



Setting Parental Controls (Rating Level)

Use this to restrict playback of adult or violent DVDs you do not want children to view.



In Stop mode, press **MENU** button.



Press Cursor ▼
button to move to
'Setup' and then
press ENTER button.



Press Cursor ▼
button to move to
'PARENTAL' and then
press ENTER button.



- Press Cursor ▲, ▼ button to select the desired rating level and then press ENTER button.
- If you have selected Level 6, you cannot view DVDs with Level 7 or higher.
- The higher the level, the closer the content is to violent or adult material.



- 5 Enter the password and then press ENTER button.
 - The password is set to "7890" by default.
 - Once the setup is complete, you will be taken to the previous screen.



Note


• This function works only if a DVD disc contains the rating level information.

Press RETURN button to return to the previous level.


Press **MENU** button to exit the setup screen.

Setting the Password

You can set the password for the Parental (rating level) setting.







Note

• The password is set to "7890" by default.

- Press Cursor ▼ button to move to 'PASSWORD' and then press ENTER button.
- 4 Press ENTER button.



PASSWORD CHANGE

CHANG

- 5 Enter the password and then press ENTER button.
 - Enter the old password, a new password, and confirm new password.
 - The setting is complete.



- Press **RETURN** button to return to the previous level.
- Press **MENU** button to exit the setup screen.



Setting the Wallpaper Des DVD







While watching a DVD, VCD or JPEG CD, you can set the image you like as background wallpaper.

Setting the Wallpaper


During playback, press PLAY/PAUSE button when the image you like comes up.



- Press LOGO button.
- "COPY LOGO DATA" will be displayed on the TV screen.



- The power will turn off and then back on and the disc tray will open automatically.
- The selected wallpaper will be displayed.
- Press **OPEN**/ **CLOSE** to close the disc tray.
- You can repeat Steps 1 and 2 to set up to 3 wallpapers.





Select this to set the Samsung Logo image as your wallpaper.



Select this to set the desired image as your wallpaper.

■ To Change the Wallpaper

- In Stop mode, press **MENU** button.
- Press Cursor ▼ button to move to 'Setup' and then press **ENTER** button.



Press Cursor ▼ button to move to 'LOGO' and then press **ENTER** button.



Press ▼ to select the desired 'USER', and then press ENTER.



Press **MENU** button to exit the setup screen.

- Press **RETURN** button to return to the previous level.
- Press MENU button to exit the setup screen.



DVD Playback Mode

Some DVD-Audio discs contain DVD-Video as well as DVD-Audio.

To play back the DVD-Video portion of the DVD-Audio disc, set the unit to DVD-Video mode.



Press the **MENU** button while the disc tray is open.



Press Cursor button to move to 'DVD TYPE' and then press ENTER button.



Press Cursor ▼
button to move to
'Setup' and then
press ENTER button.



- Press Cursor ▲,▼
 button to move to
 'DVD VIDEO' and then
 press ENTER button.
- Set steps 1 ~ 4 again if you want to switch to DVD AUDIO Play mode.



When Selecting DVD Play Mode:

- DVD VIDEO : set to play the DVD video contents contained in DVD
 - audio disc.
- DVD AUDIO : set to play the default DVD

audio.

Press **RETURN** button to return to the previous level.

Press **MENU** button to exit the setup screen.



DVD Play mode is set to DVD Audio as factory default setting.



Video may look slower than the audio if it is connected with digital TV.

In this case, adjust the delay time of audio to optimal status to fit the video.

- Press the **MENU** button.
 - Setup menu appears.



- Press Cursor ▲, ▼ buttons to move to 'Audio' and then press ENTER button.
 - 'Audio' menu appears.



- Press Cursor ▲, ▼ buttons to move to 'AV-SYNC' and then press ENTER button.
- AV-SYNC screen appears.

- Press Cursor ▲,▼ buttons to select the Delay Time of AV-SYNC and then press the ENTER button.
 - You can set the audio delay time between 0 ms and 300 ms. Set it to the optimal status.



Press RETURN button to return to the previous level.

Press **MENU** button to exit the setup screen.



Setting the Speaker Mode

Signal outputs and frequency responses from the speakers will automatically be adjusted according to your speaker configuration and whether certain speakers are used or not.

In Stop mode, press **MENU** button.



In the Speaker Setup, press the ENTER button again.



Press Cursor ▼
button to move to
'Audio' and then
press ENTER button.




Press Cursor ▲, ▼,

◀,▶ buttons to move
to the desired
speaker and then
press ENTER button.

 For C, LS, and RS, each time the button is pressed, the mode switches alternately as follows: SMALL → NONE.

• For L and R, the mode is set to SMALL.





SMALL: Select this when using the speakers.

NONE: Select this when no speakers are installed.



• Depending on PRO LOGIC and STEREO, the speaker mode may vary.



Setting the Test Tone

Press the Test Tone to check the speaker connections and to adjust the speaker levels.

In Stop mode, press **MENU** button.



Press Cursor ▼
button to move to
'Audio' and then
press ENTER button.



- Press Cursor ▼ button to move to 'TEST TONE' and then press ENTER button.
 - The test tone will be sent to L → C → R → RS → LS → SW in that order.
 If the ENTER button is pressed again at this time, the test tone will stop.





Press **RETURN** button to return to the previous level.

Press **MENU** button to exit the setup screen.


When manually testing using the $\ensuremath{\mathsf{TEST}}\xspace\ensuremath{\mathsf{TONE}}\xspace$ button

L: Front Speaker (L) C: Center Speaker SW: Subwoofer R: Front Speaker (R) LS: Rear Speaker (L) RS: Rear Speaker (R)

Press **TEST TONE** button.

- Test tone will be produced as follows: When playing a DVD or CD, this will work only in Stop mode.
- Use this function to check that each speaker is correctly connected and that there is no problem.

To end the test tone, press **TEST TONE** button.





Setting the Delay Time

If the speakers cannot be placed at equal distances from the listening position, you can adjust the delay time of the audio signals from the center and rear speakers.





In Stop mode, press **MENU** button.



Press Cursor ▼ button to move to 'Audio' and then press ENTER button.




Setting up the Speaker Delay Time

When 5.1CH Surround Sound is played, you can enjoy the best sound if the distance between you and each speaker is the same. Since the sounds arrive at the listening position at different times depending on the placement of speakers, you can adjust this difference by adding a delay effect to the sound of the Center Speaker and Surround Speakers.

Note

- With INPL (Dolby Pro Logic II), the delay time may be different for each mode.
- With AC-3 and DTS, the delay time can be set between 00 and 15mSEC.

Press Cursor ▼ button to move to 'DELAY TIME' and then press ENTER button.



Press Cursor ◀, ► to set the Delay time.

 You can set the delay time for C between 00 and 05mSEC and for LS and RS between 00 and 15mSEC.







• Setting CENTER SPEAKER


If the distance of Dc is equal to or longer than the distance of Df in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

Distance between Df and Dc	Delay Time
0.00 m	0 ms
0.34 m	1 ms
0.68 m	2 ms
1.02 m	3 ms
1.36 m	4 ms
1.70 m	5 ms

• Setting REAR (SURROUND) SPEAKERS

If the distance of Df is equal to the distance of Ds in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.


Distance between Df and Ds	Delay Time
0.00 m	0 ms
1.02 m	3 ms
2.04 m	6 ms
3.06 m	9 ms
4.08 m	12 ms
5.10 m	15 ms





Setting the Audio Quality

You can adjust the balance and level for each speaker.



Method 1 When adjusting the audio quality using the setup screen

In Stop mode, press **MENU** button.



Press Cursor ▼ button to move to 'SOUND EDIT' and then press ENTER button.



Press Cursor ▼
button to move to
'Audio' and then press
ENTER button.



Press Cursor ▲, ▼,

◀, ▶ buttons to select
the desired item and then
press ENTER button.



Press **RETURN** button to return to the previous level.

Press MENU button to exit the setup screen.

Method 2 When manually adjusting with the SOUND EDIT button

Adjusting Front Speaker Balance

Press SOUND
EDIT button and then press Cursor

00 F -01

Adjusting Rear Speaker Balance

Press SOUND EDIT button and then press Cursor

00 R -01

Adjusting Center Speaker Level

Press SOUND EDIT button and then press Cursor

CEN +OIdB

Adjusting Rear Speaker Level

Press SOUND
EDIT button and then press Cursor

REAR -018

Adjusting Subwoofer Speaker Level

Press SOUND EDIT button and then press Cursor

5W +018B

Note

Adjusting Front/Rear Speaker Balance

- You can select between 00 and -06 and OFF.
- The volume decreases as you move closer to -6.


Adjusting Center/Rear/Subwoofer Speaker Level

- The volume level can be adjusted in steps from +6dB to -6dB.
- The sound gets louder as you move closer to +6dB and quieter as you get closer to -6dB.



Setting the DRC (Dynamic Range Compression)

You can use this function to enjoy Dolby Digital sound when watching movies at low volume at night.



Press MENU button.



Press Cursor ▼
button to move to
'Audio' and then
press ENTER
button.



Press Cursor ▼
button to move to
'DRC' and then
press ENTER
button.



Press Cursor

▲, ▼ to adjust the 'DRC'.

 The more times the Cursor ▲ button is pressed, the greater the effect, and the more times Cursor ▼ button is pressed, the smaller the effect.



Press **RETURN** button to return to the previous level.


Press MENU button to exit the setup screen.


Dolby Pro Logic II Mode

You can select the desired Dolby Pro Logic II audio mode.

Press DI PL II MODE button.

• Each time the button is pressed, the mode changes as follows.





Note


 When selecting Pro Logic II mode, connect your external device to the AUDIO INPUT jacks (L and R) on the player. If you connect to only one of the inputs (L or R), you cannot listen to 5.1 channel surround sound.


PRO LOGIC II


- MUSIC: When listening to music, you can experience sound effects as if you are listening to the actual performance.
- CINEMA: Adds realism to the movie soundtrack.
- PRO LOGIC: You will experience a realistic multi-channel effect, as if using five speakers, while using just the front left and right speakers.
- MATRIX: You will hear 5.1 channel surround sound.


STEREO: Select this to listen to sounds from the front left and right speakers and the subwoofer only.













 When playing a DVD disc encoded with two or more channels, multi-channel mode will be selected automatically and INPL II (Dolby Pro Logic II) button does not work.

- PANORAMA: This mode extends the front stereo image to include the surround speakers for an exciting "wraparound" effect with side wall imaging.
- **CENTER WIDTH:** Sound is output to the center speaker only. The front left and right speakers produce phantom sound.
- **DIMENSION**: Incrementally adjusts the sound field (DSP) from the front or rear.



Setting the RRSS(Rear Reflecting Surround System)


- By setting up the RRSS function just once, the speaker distance, channel level, and rear sound reflection effect are automatically set and create an optimal listening environment.
- This function works only in DVD/CD mode.
- Connect the RRSS Microphone to the RRSS input jack.
- Place the RRSS Microphone at the listening position.
- Press the RRSS button.
- A speaker tone will be heard once from each speaker in the order of L → C → R → RS → LS → SW, and then the newly set error tone will be heard again from L → R.
- An optimal listening environment will be set up automatically.
- It takes about 2 minutes to complete the RRSS setup.



Tone Output


A piano sound will be heard and the setup will be completed.

When "REMOVE MIC" appears on the display, disconnect the RRSS Microphone.



Note

- The RRSS button works as the RRSS setup function shown above if the RRSS Microphone is connected, and works as the rear sound reflection effect function if the microphone is removed.
- If you are installing the system for the first time or if you have initialized the system, "NO MEASURED DATA" will appear on the display when you press the RRSS button without connecting the RRSS Microphone.
- During the RRSS setup, the output volume of the tone is fixed and you cannot use the volume control buttons to adjust the output level.
- If you remove the RRSS Microphone during the RRSS setup, the setup will be cancelled.
- Place the front and left speakers (L/R) toward the side walls so that the rear speaker sound is reflected against the walls.



To select the RRSS that you have set

Briefly press the RRSS button.

(If you have set the RRSS for the first time according to Steps 1 to 3 on the previous page)

- Your selection will toggle between "REAR REFLECTING ON" and "REAR REFLECTING OFF" on the display.
- Select "REAR REFLECTING ON" to listen using the RRSS setting and select "REAR REFLECTING OFF" to listen to the disc currently being played in its original setting.

To check the RRSS that you have set

- Press and hold the RRSS button twice.
 - "CHECK" appears on the display.
- 2. Next, briefly press the RRSS button.
 - The speaker distance and level value for each channel will be displayed.

To cancel the RRSS setup

Press the RRSS button.

 The tone output stops, "CANCEL" appears on the display, followed by "REMOVE MIC", and then the setup will be cancelled.

To enable or disable the sound logo

When you turn on the power, a sound logo will be heard, indicating that the disc reading is completed and the player is in its optimal condition to play the disc.

- Press and hold the RRSS button.
 - "S.LOGO ON" or "S.LOGO OFF" appears on the display.
- **2.** Briefly press the **RRSS** button.
 - Each time you press the button, your selection toggles between "S.LOGO ON" and "S.LOGO OFF".
 - Select "S.LOGO ON" to enable the sound logo and select "S.LOGO OFF" to disable the sound logo.

Caution

 If the system is installed at a location where sound cannot be reflected (e.g., an open space without walls), the speaker distance, channel level, and rear sound reflection effect may be set incorrectly during the RRSS setup.



Rear Reflecting Surround System

You can enjoy realistic sound reproduction that approximates 5.1-channel surround sound using the front speakers.

- Press the RRSS button to select "REAR REFLECTING ON".
- The rear sound reflection function will be enabled and you can enjoy the 5.1-channel surround sound.


To cancel the rear sound reflection function, press the RRSS button again to select "REAR REFLECTING OFF".


· PERP P DEF

What is RRSS?

(RRSS: Rear Reflecting Surround System)

- The sound from the front/rear speakers, which are located in the front, is first reflected against the side walls (or the ceiling) and then reflected against the rear wall before reaching the listener.
 It allows you to enjoy the realistic sound reproduction equal to that of a 5.1-channel speaker system using only 3 speakers.
- It not only increases space efficiency but eliminates the need for speaker cable arrangement because it does not require installation of rear speakers.







Live Surround Mode

You can use the magic sound field to listen to 2-channel stereo sources in realistic 5.1-channel surround sound.


Play a Dolby Surround or 2-Channel disc, or listen to the radio

To cancel the magic sound field function, press and hold the Live Surround Mode button on the main unit for longer than 1 second.

Note

- Depending on the disc being played, the effect of each sound field may vary.
- You cannot select SUPER 5.1 mode when playing a DVD disc recorded in more than 2 channels.

- 2 Each time you press the LSM + button, the mode display changes in the order shown below. Each time you press the LSM button, the mode display changes in the reverse order.
- CINEMA: A powerful sound field effect as in a movie theater.
- **STADIUM**: A sound field effect of being at a soccer or baseball game.
- LIVE: A sound field effect with a spatial feeling as in a live concert hall.
- JAZZ : Select this when listening to jazz.
- ROCK: Select this when listening to rock music.
- CLASSIC : Select this when listening to classical music.
- DISCO: A sound field with a powerful bass as in a disco club.
- SUPER 5.1: Select this to listen to a 2 channel source in 5.1 channel.
- LSM OFF: If you press the Live Surround Mode button on the main unit, the mode display will appear on the display in the same order as pressing the LSM + button on the remote control.





SURROUND PLUS / Virtual Headphone

The Surround Plus function works when the headphone is not connected, and the Magic Headphone function works when the headphone is connected.



Enable the Surround plus function if you have installed the system at a location where sound cannot be reflected. You can create a virtual rear sound image to enjoy realistic sound reproduction that approximates 5.1-channel surround sound. (When you enable this function, the center speaker does not produce sound and the disc will be reproduced in 4.1-channel.)

- Press the **SURR. PLUS** button to select the surround plus function.
- A realistic sound very similar to that of a 5.1-channel sound system will be produced.

- 2 To cancel the surround plus function, press the SURR. PLUS button again.
 - You can listen in regular stereo.





- This function works only with DVDs recorded in more than 2 channels.
- The surround plus function does not work with 2-channel sources such as music CDs or MP3 CDs.

■ Virtual Headphone


You can enjoy a realistic sound very similar to that of a 5.1-channel sound system using regular stereo headphones.

- Press the V-H/P button to select "VIRTUAL ON".
- You can enjoy the feeling of being in the middle of a concert hall using headphones.

· VIRTUAL ON

- To cancel this function, press the V-H/P button to select "VIRTUAL OFF".
- You can listen in a regular 2-channel stereo.

°° VIRTUAL OFF



- Press the SUPER 5.1 button to select "SUPER 5.1".
- A 2-channel source will be reproduced in 5.1 channel.

To cancel this function, press the SUPER 5.1 button to select "SUPER OFF".

Note

• If you insert a DVD recorded in more than 2 channels and press the SUPER 5.1 button, "THIS FUNCTION APPLIES ONLY 2CH SOURCE" will appear on the display and the function will not work.



Listening to Radio

You can listen to the chosen band (FM, AM broadcast stations) by using either the automatic or manual tuning operation.

Remote Control Unit

Press TUNER/ BAND button.

 The selection toggles back and forth between "FM → AM" each time the TUNER(BAND) button is pressed. Tune in to the desired station.

Automatic Tuning 1

When I◄◄►►I is pressed, a preset broadcast station is selected

Automatic Tuning 2

Press and hold 🛇 to automatically search for active broadcasting stations.

Manual Tuning

Briefly press 🛇 v to increase or decrease the frequency incrementally.

Main Unit

Press the Function button to select the desired band (FM, AM).

2 Select a broadcast station.


Automatic Tuning 1 Press the **STOP** (■)

PRESET and then press I ► button to select the preset station.

Automatic Tuning 2 Press the STOP (■) button to select "MANUAL" and

then press and hold I◀◀ ▶▶I button to automatically search the band.

Manual Tuning Press STOP (■) to select MANUAL and then briefly press I◄◀ ▶►I to tune in to a lower or higher frequency.



Press MO/ST button to listen in Mono/Stereo.

(This applies only when listening to an FM station.)

- Each time the button is pressed, the sound switches between "STEREO" and "MONO".
- In a poor reception area, select MONO for a clear, interference-free broadcast.



Example: Presetting FM 89.1 in the memory

♦ 15 AM stations

- Press the TUNER(BAND)
 button and select the FM band
 - Each time the button is pressed. the band switches between "FM → AM".

AM ······ Medium Wave

• Refer to Step 2 on page 63 to automatically or manually tune in to a station.



- Press the **TUNER** MEMORY button
 - "PRGM" flashes in the display. Tune in to a station.



- Press ►► to select preset number.
 - You can select between 1 and 15



- Press the **TUNER MEMORY** button again.
- Press the TUNER MEMORY button before 'PRGM' disappears from the display.
- 'PRGM' disappears from the display and the station is stored in memory.



To preset another station, repeat steps 2 to 5.

To tune in to a preset station, press ► on the remote control to select a channel.



About RDS broadcasting

Using the RDS (Radio Data System) to receive FM stations

RDS allows FM stations to send an additional signal along with their regular program signals. For example, the stations send their station names, as well as information about what type of program they broadcast, such as soorts or music.etc.

When tuned to an FM station which provides the RDS service, the RDS indicator lights up on the display.

- Description on RDS function
- 1. PTY (Program Type): Displays the type of programme currently being broadcast
- PS NAME (Program Service Name): Indicates the name of broadcasting station and is composed of 8 characters.
- RT (Radio Text): Decodes the text broadcast by a station (if any) and is composed of maximum 64 characters.
- 4. CT (Clock Time): Decodes the real time clock from the FM frequency.
 - Some stations may not transmit PTY, RT or CT information therefore this may not be displayed in all cases.
- 5. TA (Traffic Announcement): When this symbol flashes it shows that the traffic announcement is in progress.



- RDS is not available for AM broadcasts.
- RDS may not operate correctly if the station tuned is not transmitting RDS signal properly or if the signal strength is weak.

What information can RDS signals provide?

You can see the RDS signals the station sends on the display.

TO show the RDS signals

Press RDS DISPLAY while listening to an FM station.

Each time you press the button, the display change to show you the following information:

$$\rightarrow$$
 PS NAME \rightarrow RT \rightarrow CT \rightarrow Frequency

PS (**Program Service**): While searching, "**PS**" appears and then the station names will be displayed. "**NO PS**" appears if no signal is sent.

RT(RadioText): while searching, "RT" appears and then text messages the station sends will be displayed. "NO RT" appears if no signal is sent.

Frequency: station frequency (non-RDS service)


About characters shown in the display


When the display shows PS,or RT signals,the following characters are used.

- The display window cannot differentiate upper case and lower case letters and always uses upper case letters.
- The display window cannot show accented letters, "A," for instance, may stans for accented "A's" like "A, A, Ä, Ä, Å, Åand Ã."



• If searching finishes at once, "PS", and "RT" will not appear on the display.





PTY (Program Type) indication and PTY-SEARCH function

One of the advantages of the RDS service is that you can locate a particular kind of program from the preset channels by specifying the PTY codes.


To search for a program using the PTY codes

Before you start, remember...

- The PTY Search is only applicable to preset stations.
- To stop searching any time during the process, press PTY SEARCH while searching.
- There is a time limit in doing the following steps.
 If the setting is cancelled before you finish, start from step 1 again.
- When pressing the buttons on the primary remote control, make sure that you have selected the FM station using the primary remote control.
- Press PTY SEARCH while listenning to an FM station.
- Press the PTY-or PTY+until the PTY code you want appears on the display.
 - The display gives you the PTY codes described to the right.
- Press PTY SEARCH again, while the PTY code selected in the previous step is still on the display.
 - The center unit searches 15 preset FM stations, stops when it finds the one you have selected, and tunes in that station.

Display	Program Type	
NEWS	News including an announced opinion and report	
AFFAIRS	Several matters including a current incident, documentary, discussion and analysis.	
INFO	 Information including weights and measures, returns and forecast, matters interesting the customer, medical information, etc. 	
SPORT	• Sports	
EDUCATE	Education	
DRAMA	Drama-Radio serial, etc.	
CULTURE	Culture-National or local culture including the religious problem, social science, language, theater,etc.	
SCIENCE	Natural science and technology	
VARIED	Others-Speech, amusing program (quiz, game), interview, comedy and satirical play, etc.	
POP M	Pop music	
ROCK M	Rock music	
M.O.R.M	Current contemporary music considered to be "easylistening."	
LIGHT M	Light classical music- Classical music and instrumental and chorus music	
CLASSIC	Heavy classical music-Orchestra music, symphony, chamber music and opera	
OTHER M	Other music - Jazz, R&B country music	
WEATHER	• Weather	
FINANCE	• Finance	
CHILDREN	Children's programmes	
SOCIAL A	Social affairs	
RELIGION	• Religion	
PHONE IN	• Phone in	
TRAVEL	• Travel	
LEISURE	• Leisure	
JAZZ	• Jazz Music	
COUNTRY	Country Music	
NATION M	National Music	
OLDIES	Oldies Music	
FOLK M	Folk Music	
DOCUMENT	Documentary	

Convenient Functions



- Sleep Timer Function

You can set the time that the DVD player will shut itself off.

Press **SLEEP** button.

 "SLEEP" will be displayed. Each time the button is pressed the preset time changes as follows: 10 → 20 → 30 → 60 → 90 → 120 → 150 → OFF.



To confirm the sleep timer setting, press **SLEEP** button.

- •The remaining time before the DVD player will shut itself off is displayed.
- Pressing the button again changes the sleep time from what you have set earlier.

To cancel the sleep timer, press **SLEEP** button until OFF appears on the display.



- - Adjusting Display Brightness

You can adjust the brightness of the display on the main unit so it won't interfere with your movie viewing.




This is useful when answering a doorbell or telephone call.

Press **DIMMER** button.

• Each time the button is press, the brightness changes as follows: SLIGHTLY DARK → DARK → BRIGHT.

Press **MUTE** button.


- 'MUTE' flash in the display.
- To switch the sound back on (at the same volume as before), press MUTE again or the VOLUME buttons.



Using Headphones


Use headphones (not supplied) for private listening pleasure.

Connect the headphones to the PHONES jack for private listening.



Caution

• To prevent hearing damage, do not increase the volume excessively when using headphones.



When operating a TV with the remote control

- Press the **MODE** button to make the TV indicator on the remote control flash.
 - TV DVD RECEIVER
- Press **POWER** button to turn on the TV.
- 3 Point the remote control toward the TV.
- While holding down **POWER**, enter the code corresponding to your brand of TV.
 - If the code matches the TV's code, the TV will be turned off.
 - If there is more than one code listed for your TV in the table, enter one at a time to determine which code works.

Example: For a Samsung TV

While holding down **POWER**, use the number buttons to enter 00, 01, 02, 03, 04, and 05.

- Pont the remote control toward the TV and press POWER. If the TV turns off or on, the setting is complete.
 - You can use the TV POWER, VOLUME, CHANNEL, and Numeric buttons (0~9).

Note

- The remote control may not work on some brands of TVs. Also some operations may not be possible depending on your brand of TV.
- If you do not set the remote control with the code for your brand of TV, the remote control will work on a Samsung TV by default.

TV Brand Code List

No.	Brand	Code	No.	Brand	Code
1	SAMSUNG	00(Initial Value), 01, 02, 03, 04, 05, 73	30	BRANDT	41
2	ANAM 06~11,59		31	FERGUSON	41
3	DAEWOO	12~18, 20, 21	32	PIONEER	41, 48, 74
4	LG	05, 20, 21, 22, 53	33	TELEAVA	41
5	HITACHI	23, 40, 41, 49	34	FINLUX	05, 42, 47
6	JVC	24,55	35	FISHER	31
7	SHARP	27, 33, 34, 35, 54	36	AKAI	31
8	SONY	27,36	37	YOKO	05
9	TOSHIBA	27, 37, 42, 43, 44, 46	38	PHONOLA	05, 45, 47
10	SANYO	27, 30, 31, 32	39	RADIOLA	05,45
11	MITSUBISHI	05, 27, 28	40	SCHNEIDER	05
12	MATSUSHITA	09, 26	41	NEWSAN	58
13	TELEFUNKEN	41, 49, 51, 57	42	CONTINENTAL EDISON	49
14	RCA	29,61	43	SALORA	48
15	PANASONIC	07, 09, 26, 48, 49, 50	44	SELECO	48
16	SABA	40, 41, 47, 48, 49	45	NOKIA	48
17	PHILIPS	05, 45, 47, 64, 65, 66, 67, 68, 69	46	REX	48
18	GRUNDIG	39, 42, 46, 70, 71, 72	47	MIVAR	46
19	ZENITH	38	48	IMPERIAL	46
20	MIVAL	52	49	CGE	46
21	NOBLEX	56	50	BANG & OLUFSEN	47
22	EMERSON	19	51	BRIONVEGA	47
23	MAGNAVOX	25	52	FORMENTI	47
24	LOEWE	05,60	53	METZ	47
25	THOMSON	40, 41, 49, 62, 63	54	WEGA	47
26	NORDMENDE	40, 41, 49	55	RADIOMARELLI	47
27	LOEWE OPTA	36, 47, 05	56	SINGER	47
28	BLAUPUNKT	39	57	SINUDYNE	47
29	SIEMENS	39			

Before Calling for Service

Refer to the chart below when this unit does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, turn off the unit, disconnect the power cord, and contact the nearest authorized dealer or Samsung Electronics Service Center.

Symptom	Check/Remedy
Disc tray does not open.	Is the power cord plugged securely into the outlet?Turn off the power and then turn it back on.
Playback does not start.	 Check the region number of the DVD. DVD discs purchased from abroad may not be playable. CD-ROMs and DVD-ROMs cannot be played on this DVD player. Make sure that the rating level is correct.
Playback does not start immediately when the Play/Pause button is pressed.	 Are you using a deformed disc or a disc with scratches on the surface? Wipe the disc clean.
Sound is not produced.	 No sound is heard during fast playback, slow playback, and step motion playback. Are the speakers connected properly? Is the speaker setup correctly customized? Is the disc severely damaged?
Sound can be heard only from a few speakers and not all six.	 When listening to a CD or radio, sound is output to the front speakers (L/R) only. Select "PRO LOGIC II" by pressing □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □
Picture does not appear, sound is not produced, or the disc tray opens 2 to 5 seconds later.	 Was the DVD player suddenly moved from a cold place to a warm one? When condensation forms inside the player, remove the disc and let the player stand for 1 or 2 hours with the power on. (You can use the player again after condensation disappears.)
Dolby Digital 5.1 CH Surround Sound is not produced.	 Is there "Dolby Digital 5.1 CH" mark on the disc? Dolby Digital 5.1 CH Surround Sound is produced only if the disc is recorded with 5.1 channel sound. Is the audio language correctly set to DOLBY DIGITAL 5.1-CH in the information display?

Symptom	Check/Remedy
 Disc is rotating but no picture is produced. Picture quality is poor and picture is shaking. 	 Is the TV power on? Are the video cables connected properly? Is the disc dirty or damaged? A poorly manufactured disc may not be playable.
The remote control does not work.	 Is the remote control being operated within its operation range of angle and distance? Are the batteries exhausted? Have you select the mode(TV/DVD) functions of the remote control (TV or DVD) correctly?
Audio language and subtitles do not work.	Audio language and subtitles will not work for DVDs not containing them. And depending on the disc, they may work differently.
Menu screen does not appear even when the menu function is selected.	Are you using a disc that does not contain menus?
Aspect ratio cannot be changed.	 You can play 16:9 DVDs in 16:9 WIDE mode, 4:3 LETTER BOX mode, or 4:3 PAN SCAN mode, but 4:3 DVDs can be seen in 4:3 ratio only. Refer to the DVD disc jacket and then select the appropriate function.
Can't receive radio broadcast.	 Is the antenna connected properly? If the antenna's input signal is weak, install an external FM antenna in an area with good reception.
 The main unit is not working. (Example: The power goes out or strange noise is heard.) The DVD player is not working normally. 	 Turn off the power and hold the button on the main unit for longer than 5 seconds. Using the RESET function will erase all stored settings. Do not use this unless necessary.
The password for rating level has been forgotten.	 While "NO DISC" message appears on the display of main unit, hold the main unit's button for longer than 5 seconds. "INITIALIZE" appears on the display and all settings will return to the default values. Press the POWER button. Using the RESET function will erase all stored settings. Do not use this unless necessary.

Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause skipping. Be especially careful not to scratch discs when handling them.

Handling discs



Do not touch the playback side of the disc. Hold the disc by the edges so that fingerprints will not get on the surface.

Do not stick paper or tape on the disc.

Disc Storage

Do not keep in direct sunlight



Keep in a cool ventilated area



Keep in a clean Protection jacket. Store vertically.



Caution

- Do not allow the discs to become contaminated with dirt.
- Do not load cracked or scratched discs.

Handling and Storing Discs



When you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth

• When cleaning, wipe gently from the inside to the outside of the disc.

Note

 Condensation may form if warm air comes into contact with cold parts inside the player. When condensation forms inside the player, the player may not operate correctly. If this occurs, remove the disc and let the player stand for 1 or 2 hours with the power on.

/ISCELLANEOUS


Specifications

G	Power Consumption	90W		
E	Weight 4Kg			
G E N E R	Dimensions (W x H x D)	360 x 65 x 394 mm	5	
R A	Operating Temperature Range	+5°C~+35°C		
L	Operating Humidity Range	10%~75%		
Т	Usable Sensitivity	10dB		
F U	S/N Ratio	55dB		
F N E R	Distortion	0.8%		
	Usable Sensitivity	60dB		
A M ER	S/N Ratio	35dB		
IVI E R	Distortion	2%		
	Composite Video	1.0Vp-p(75Ω load)		
v O		Compositive Video : 1.0Vp-p(75Ω load)		
OUTPUT	Scart Jack			
Ĕ		RGB Signal : 0.714Vp-p(75Ω load)		
Ο̈́T	0	Y:1.0Vp-p(75Ω load)		
	Component Video	Pr:0.70Vp-p(75Ω load)		
_	Front speaker output	Pb:0.70Vp-p(75 Ω load) 60W x 2(4 Ω)		
A M	Center speaker output			
P	Rear speaker output	60W(4Ω)		
Ĺ	Subwoofer speaker output	60W x 2(4Ω) 100W(4Ω)		
<u>l</u>	Frequency range	20Hz~20kHz		
F	S/N Ratio	70dB		
Ė	Channel separation	60dB		
R	Input sensitivity	(AUX)400mV		
		5.1ch speaker system		
	Speaker system	Front/Center/Rear speaker	Subwoofer speaker	
S P	Impedance	4Ω x 5	4Ω	
E	Frequency range	150Hz~20kHz	30Hz~150Hz	
Ā	Output sound pressure level	85dB/W/M	86dB/W/M	
K E R	Rated input	60W	100W	
	Maximum input	120W	200W	
	Dimensions (W x H x D)	Front/Rear 114 x 182 x 198 mm		
	Weights	Center 257 x 123 x 110 mm	205 x 350 x 460 mm	
		Front/Rear 1.3 kg		
		Center 1.2 kg	8.5 Kg	

78

Notes on Terminology

ANGLE	Recorded onto some DVD discs are scenes which have been simultaneously shot from a number of different angles (the same scene is shot from the front, from the left, from the right, etc.). With such discs, the Angle button can be used to change the angle of view for specific scenes.
CHAPTER NUMBER	These numbers are recorded on DVD discs. A Title is subdivided into many sections, each of which is numbered, and specific parts of the video can be searched quickly using these numbers.
DVD	A high-density optical disc on which high-quality pictures and sound have been recorded by means of digital signals. Incorporating a new video compression technology (MPEG-2) and high-density recording technology, a DVD disc comprises two 0.6 mm thick discs bonded together.
PCM	An acronym for Pulse Code Modulation - another name for digital audio.
PBC (PLAYBACK CONTROL)	This is recorded on a video CD (version 2.0). Selected scenes or information can be chosen from the menu displayed on the TV monitor.
REGION NUMBER	Both the DVD player and DVD discs are encoded with a region number. If the region number on the DVD disc does not correspond to the region number of the DVD player, the player cannot play the disc.
SUBTITLES	Translated appearing at the bottom of the screen. A DVD disc can contain up to 32 subtitle languages.
TITLE NUMBER	These numbers are recorded on DVD discs. When a disc contains two or more movies, these movies are numbered as Title 1, Title 2, etc.
TRACK NUMBER	These numbers are assigned to the tracks which are recorded on video and audio CDs. They enable specific tracks to be located quickly.
VIDEO CD	Contains recordings of pictures and sound whose quality is roughly comparable to that of video tape. This player also supports video CDs with playback control (version 2.0).
DIGITAL	You can enjoy 5.1 (or 6) channels of high fidelity digital sound from various digital input sources such as DVD, CD etc. DTS provides a realistic, clear surround sound that has not previously been available from conventional surround sound.
DIGITAL	5.1 (or 6) Channel Digital Surround sound reproduced from DVDs and LDs recorded as a digital signals (with DIGITAL disc marking). With better sound quality, dynamic range, and directionality than traditional Dolby surround technology, you can enjoy dynamic, realistic sound.
DOLBY DIGITAL PRO LOGIC II	A 4 channel analog sound reproduced from a program source such as a videotape or LD with the mark. You can enjoy a more realistic, robust sound unavailable from regular stereo sources.



THIS APPLIANCE IS MANUFACTURED BY:

